

VEEMET Central Wear Cap M

Installation procedure



DISCLAIMER

© MTG, all rights reserved

The brands identified with an asterisk do not belong to METALOGENIA S.A. and this organization refers to them only to identify the destination of its products, without there being any relationship between METALOGENIA S.A. and the legitimate owners of any such brands.

Copy right: It is strictly forbidden for any person not belonging to MTG to distribute all or any part of the material set out in this document unless they are authorized to do so.

Liability: To ensure the correct use and handling of the MTG products without risk, please carefully read the corresponding service instructions set out on the MTG website. MTG will not be held liable for damages, loss, injury, or death arising from incorrect use or failure to heed the provisions of this guide. Similarly, MTG will not be held liable for damages caused due to the faulty installation or handling of its products. MTG likewise declines all liability for recommendations related to the use or handling of MTG products set out in documents not expressly authorized by MTG.

1. SAFETY

The practices described in this manual can be taken as guidelines for operating safely in many conditions and in addition to the safety standards that are current and enforceable in your area or region.


Your safety and the safety of third parties is the result of putting into practice your knowledge of the correct operational procedures.

Attention, when performing the work described in these instructions, always work safely and use the personal protection elements required to minimize or avoid injury. Always wear:



To avoid eye injury, always wear safety goggles or a protective mask when using any equipment, hammer or similar tool. When equipment is under pressure or when objects are struck, chips or other debris can be thrown out. Make sure no one gets hurt by the debris that is fired before applying pressure or hitting an object. Wear eye protection that complies with ANSI Z87.1 and OSHA standards. Also wear hearing protection and gloves.

Lifting a heavy object can cause serious or fatal injury. DO NOT exceed the maximum rated capacity of lifting and positioning devices: Stay away from the area under a suspended load.










2. IMPORTANT

Read the full document prior to start any operation since there may be some steps which may require previous verifications/operations.


This procedure is valid for the installation of "M" and "MS" style wear caps and is valid for all sizes of the VeeMet range.

3. INSTALLATION PROCEDURE

3.1 Slide the wear cap through the lateral guides of the adapter before installing the tooth.




3.2 Insert the tooth and secure it by means of the pin. If required, see the installation and removal procedure of VeeMet teeth.






4. REMOVAL PROCEDURE

4.1 Unlock and remove the pin by means of the removal tool and. Then, remove the tooth. If required, see the installation and removal procedure of VeeMet teeth.



4.2 Remove the wear cap by pulling it out from the adapter.



4.3 Thoroughly clean the top area of the adapter and the guides prior to installing a new wear cap.



Service Instructions

The latest welding recommendations and assembly / disassembly instructions can be found online: www.mtgcorp.com/manuals

Please contact Technical Services in case of questions: technical.services@mtg.es



MTG HEADQUARTERS Carrer d'Àvila, 45 08005 Barcelona (Spain) (+34) 93 741 70 00 info@mtg.es

MTG NORTH AMERICA

4740 Consulate Plaza Drive Houston, TX 77032 (USA) +1 (281) 872 1500 info@mtgcorp.us **MTGAUSTRALIA**

16 – 18 Thorpe Close Welshpool, WA, 6106 (AUS) +61 8 6248 6513 Info.australia@mtg.es